# **Innovative FLOATLESS** Technology

SJE-Rhombus<sup>®</sup> introduces the C-Level<sup>™</sup> Sensor for use with select Installer Friendly Series panels.

### C-Level™ Sensor Patent Pending

The C-Level™ sensor detects the liquid level in the tank and sends a signal to the IFS panel, which displays this level in inches or centimeters for easier monitoring of the system. Pump activation and alarm levels can be adjusted using panel touch pad, eliminating the need to go into the tank for manual adjustment.

#### C-Level™ Sensor Features:

- Compact design works well in confined space applications
- Operates on low voltage
- One sensor replaces up to 4 floats
- Easy to install and adjust set points
- Works with most Installer Friendly Series® control panels


See reverse side for complete details on Installer Friendly Series® control panels.



22650 County Highway 6, PO Box 1708 Detroit Lakes, MN 56502 USA 1-888-DIAL-SJE Fax: 218-847-4617

www.sjerhombus.com

©SJE-Rhombus 04/11



Float tree not included.

## Installer Friendly Series® Control Panels

The innovative **Installer Friendly Series**<sup>®</sup> control panels from SJE-Rhombus<sup>®</sup> feature an **easy-to-use touch pad** on the inner door for programming and monitoring system information.

- IFS Single Phase Simplex and Duplex Demand/TD
- IFS Three Phase Simplex and Duplex Demand/TD
- IFS Single Phase Capacitor Start/Run Simplex and Duplex
- IFS InSite<sup>®</sup> Event Monitoring Simplex and Duplex Demand/TD

### **IFS PANEL FEATURES:**


- NEMA 4X weatherproof enclosure for indoor/outdoor use
- Inner door for added safety
- New innovative circuit board design offers a clean installation
- Separate control and alarm fuses
- Digital display board is standard
- Alarm beacon and horn (85 decibel rating) provides audio/visual warning of alarm condition
- Test / normal / silence switch
- Panel can be easily converted to either demand dose to timed dose in the field
- Easy to read float/pump wiring diagram
- Instruction label on inside cover for viewing and programming digital display
- Includes step-by-step installation instructions







1-888-DIAL-SJE (1-888-342-5753) www.sjerhombus.com | Section | Control | Cont



#### **TOUCH PAD/DISPLAY FEATURES:**

- Easy-to-use touch pad for programming pump control
- Pump run indicator(s)
- Status indicators, including low water alarm
- HAND/OFF/AUTO pump control switch(es)
- Hand mode safety feature
- Six digit LED display (now a standard feature) includes:
  - Liquid level in tank in inches or centimeters (C-Level<sup>™</sup> Sensor)
  - Elapsed time meter(s)
  - Cycle counter(s)
  - Alarm counter
  - Lead/Lag Selector toggles pump operation (duplex models)
  - Float error counter
  - Override counter (timed dose)